

5 Ways to Reduce *Premature Fabric Saturation*

- 1. Use High Viscosity Binder**
- 2. Use AASHTO (4.1oz/sy) Fabric**
- 3. Lower Embedment Temperature**
- 4. Lower Embedment Pressure**
- 5. Accomplish work during coolest hours
of day or night**

If bleeding still occurs, spread A/C over in-place Fabric